




**Fig. 1**




**Fig. 2**



**Fig. 3**




**Fig. 4**




AVL — Available for use by system software  
 BASE — Segment base address  
 D/B — Default operation size (0 = 16-bit segment; 1 = 32-bit segment)  
 DPL — Descriptor privilege level  
 G — Granularity  
 LIMIT — Segment Limit  
 P — Segment present  
 S — Descriptor type (0 = system; 1 = code or data)  
 TYPE — Segment type

**Fig. 5**



**Fig. 6**



**Fig. 7**